PC2TV WiFi

Wireless Computer to TV via WiFi

User's Manual

FEDERAL COMMUNICATIONS COMMISSION

This device complies with Part 15 of the FCC Rules Operation is subject to the following two conditions: this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no grantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notice: Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

CE DECLARATION

This device complies with CE . These limits are designed to provide reasonable protection against harmful interface in a residential installation.

Printed in TAIWAN R.O.C No. **03292011**
All contents are subject to change without notice.
All trademarks are the property of their respective owner.

TABLE OF CONTENTS

CHAPTER 1. OVERVIEW..... 1
1.1 Introduction..... 1
1.2 Features..... 1
1.3 Specifications..... 1
1.4 System Requirements..... 2
1.5 Package Contents..... 2
1.6 Application..... 2

CHAPTER 2. OUTLINE DESCRIPTION..... 3

CHAPTER 3. SOFTWARE INSTALLATION..... 4

CHAPTER 4. HARDWARE INSTALLATION..... 6
4.1 PC2TVwifi Connection..... 6
4.2 AP Mode Connection..... 6
4.3 STA Mode Connection..... 7
4.4 Other Connection..... 9

CHAPTER 5. BASIC OPERATION..... 10
5.1 Starting..... 10
5.2 Advanced “Play” Management of PC2TVwifi Utility..... 11
5.3 PC2TV Control..... 12
5.4 Extend Mode For Windows 7..... 13
5.5 Upgrade the PC2TVwifi Device..... 13

CHAPTER 6. TROUBLESHOOTING..... 14

1.1 Introduction

The PC2TVwifi delivers High resolution from your computer wirelessly to your home entertainment center; it brings your laptop/PC contents to the big size TV/LCD Monitor/Projector wirelessly via standard Wi-Fi technology. Providing Wi-Fi transmission/receiver up to 180 feet (open site). You can now enjoy Movie, Internet TV, Games, and Business Proposal on big screen without cable limitation and hassling. It is an ideal solution for both home and office use.

1.2 Features

- Wireless connectivity from computer to TV, monitors, projectors via Wi-Fi
- Build-in Wi-Fi module and antenna
- Same display both on Computer and TV/Monitor simultaneously
- Extend display on Computer and TV/Monitor in Windows 7 system.
- Long distance wireless transmission upto 180 feet (open site)
- VGA output, compatible with LCD TV/ Monitor /Projector
- Delivers smooth high-resolution up to 1440x900.
- Support 192kHz, 24-bit stereo audio
- PC/Movie mode performance switchable
- Output display overscan adjustable
- Complies with IEEE 802.11n, IEEE 802.11g, IEEE 802.11b.
- Support resolution up to 1440x900 by 30 fps.
- Wireless USB mouse/keyboard support.
- Ports include : 1 x USB 2.0, VGA out, 3.5mm Speaker out, and RJ-45 Ethernet.
- USB Flash disk for firmware upgrade.

1.3 Specifications

- Video:
  - Supports resolution up to 1440 x 900.
  - Duplication mode (mirrors the computer’s screen).
  - Extend mode (Windows 7)
- Audio :
  - 3.5mm Speaker out.
  - 192kHz, 24-bit stereo sound
- Wirelessly :
  - Frequency : 2.4 GHz ISM Bands 2.412-2.484 GHz
  - Modulation : 802.11 g/n: OFDM, 802.11b: CCK(11, 5.5Mbps), QPSK(2Mbps), BPSK(1Mbps)
  - Compliant with IEEE802.11n Draft 3.0 standard.
  - High speed wireless connection up to 150Mbps.
  - Meets 64/128-bit WEP, WPA, and WPA2 security standards.
  - Output Power :

    802.11b: 16 dBm +/-1.5dBm (11Mbps)

    802.11g: 14 dBm +/-1.5dBm (54Mbps)

    802.11n: 13 dBm +/-1.5dBm (HT20 MCS7)11 dBm +/-1.5dBm (HT40MCS7)

- Receive Sensitivity :
  802.11b: 11M -76 dBm
  802.11g: 54M -67dBm
  802.11n: HT20 MCS7 -64dBm , HT40 MCS7 -61dBm

- USB :
  - USB HID mouse/keyboard
  - USB Flash disk for firmware upgrade.
- Power consumption :
  - 5V DC , 730mA (max.)
- Dimensions :
  - 133 x 71 x 27 (mm)
- Antenna :
  - Omni directional Antenna.
  - Built-in Antenna.

1.4 System Requirements

- Windows XP X86/64 / Windows Vista X86/64 / Windows 7 X86/64
- 802.11 b/g/n Wi-Fi or 10/100 Mbps Ethernet.
- CD-ROM drive (For software installation)
- Display device with VGA input (e.g. TV/Monitor/Projector)

Basic Requirements:

- Intel Pentium4; 3.0G or above
- 1GB of RAM or above

Recommend Requirements:

- Core2Duo 2.0G or better
- DDR2-800, 2GB or better of RAM.
- Graphic : Chipset integrated (Intel GMA X3100) or better
  NVIDIA GeForce 8400 GS / ATI Radeon X300 stand along graphic chip or better

1.5 Package Contents

- PC2TVwifi device x 1
- DC5V power adapter x 1
- PC2TV Software / Manual CD x 1
- Quick Installation Guide x 1

1.6 Application



2. Outline Description

1. : USB port for HID device(Keyboard, Mouse…..)
2. **Power Button :** Power ON / OFF
3. **DC5V :** Power in.
4. : Audio out; Connect to external speaker / headphone.
5. **VGA :** VGA out; Connect to TV or monitor with VGA input port.
6. **LAN :** Optional application to connect computer or router via network cable.



3.1 Software Installation

3.1.1 Please insert "Multimedia Installation Kit" CD-ROM into your CD-ROM drive; AutoRun will start running. (if AutoRun didn't run, please go to "My Computer", click CD-ROM drive)

3.1.2 Please select "PC2TVwifi" product.

3.1.3 Please select "Application Software"

3.1.4 Setup wizard is running.

3.1.5 Follow instructions to finish installation.

3.1.6 After drivers and utility installed, the PC2TV benchmark tool would be prompted to evaluate your computer.

Click "**Analysis**"
to evaluate your computer.

or

Click "**Close**"
to close the PC2TV benchmark tool.
(Skip 3.1.7)

3.1.7 After evaluated, it will show the capability of your computer for PC2TV application. (**Note 1**)

3.1.8 After the benchmarking is done, please restart your computer.

3.1.9 After restart your computer, Please check the Device Manager, PC2TV application is installed successful in your computer.

Device Manager


Sound, video and game controllers
NVIDIA High Definition Audio
Realtek High Definition Audio
WonderMedia SmartStream Audio

Note: In Windows 7/ Vista, AC'97 Audio device, the audio device will be changed to "WonderMedia SmartStream Audio" when the first time install software, it may cause your computer no sound, please change the audio device to AC'97 Audio manually after the first time install software. See TROUBLESHOTING Q2.2

Note 1

Star Level in PC2TV Benchmark Tool

The following star level is to evaluate your computer, and then give you some suggestions to run PC2TVwifi application.

Stars	Level	Explanation
1 star	Lowest	The capability of CPU and Graphic are poor to support PC2TVwifi application.
2 stars	Low	Acceptable for picture/music playback and web surf, but suggested to downgrade the desktop resolution to support video playback.
3 stars	Fair	Fair for picture/music playback and web surf; sometimes lag for video playback.
4 stars	Good	Smooth to support web surf and video playback.
5 stars	Excellent	Great capability to support PC2TVwifi application.

If you get poor star level in Windows 7 / Vista, it is recommended to Choose a "Basic and High Contrast Themes" instead of "Aero Themes" and run "PC2TV Benchmark" again.

1. Right click the desktop and select Personalize.



2. Choose a "Basic and High Contrast Themes" instead of "Aero Themes".



3. Close the window.

4.1 PC2TVwifi Connection

4.1.1 AP Mode (without internet)



4.1.2 STA Mode (with internet)



4.2 AP Mode Connection

4.2.1 Hardware Connection



(1) Properly connect VGA (PC2TVwifi) output port to TV / Monitor / Projector / etc…

(2) Connect power adapter to “DC5V” (PC2TVwifi) power jack.

(3) Power on PC2TVwifi device. Waiting around **40~60 seconds**. And then it will run into the **Ready** screen.
(If waiting over 60 seconds, please restart PC2TVwifi)



- The screen of PC2TVwifi device should stay at the waiting screen as the picture.

- The device information and Wi-Fi configuration are shown as well.

4.2.2 Wi-Fi Connection

After the PC2TVwifi device is ready, please link your computer's Wi-Fi to the "device SSID" of the PC2TVwifi device.



- The default of "device SSID" is "**PC2TVwifi**".



- After the Wi-Fi was linked, please go to Wireless Network Connections -> Status -> Details to check IPv4 address; The IPv4 address should have gotten **192.168.10.x**

4.3 STA Mode Connection

4.3.1 Hardware Connection

(1) Properly connect TV / Monitor / Projector / etc… to VGA (PC2TVwifi) output port.

(2) Connect Network on PC2TVwifi (Wi-Fi or LAN).

(3) Connect power adapter to "DC5V" (PC2TVwifi) power jack.

(4) Power on PC2TVwifi device. Waiting around **40~60 seconds**. And then it will run into the **Ready** screen.
(If waiting over 60 seconds, please restart PC2TVwifi)



NOTE: Please make sure the Ethernet cable is properly connected on PC2TVwifi then power on the device.

4.3.2 Network Setting

Follow **5.1 PC2TVwifi starting**, double click on PC2TV icon,

Go to advance menu

click to make network setting.

Change the SSID and KEY, The settings for SSID and KEY have to be the same as the setting in wireless router (the default SSID name is PC2TVwifi) After change please click “save” and restart PC2TVwifi Device, then connect the PC wifi to the router.



Note:

1. Require Router support DHCP and set DHCP function on.

2 . The SSID name can not enter space.

4.3.3 Computer Wi-Fi Connection

After the PC2TVwifi device is ready, please link your computer’s Wi-Fi to the “device SSID” of your router setting.



- Link to your router SSID name

- The WEP/WPA/WPA2 key may be required, based on your PC2TVwifi network setting.

4.4 Other Connection



5.1 Starting

NOTE: We suggest turn off screensaver on your computer when using PC2TVwifi.

5.1.1 Double click the icon on desktop.

5.1.2 After starting application, you can see the PC2TVwifi control window and start to search the PC2TVwifi device.

Note: If you are waiting around 1 minute and PC2TVwifi still can not search the device, Please see TROUBLESHOOTING Q.4 Page 16

5.1.3 When getting PC2TVwifi device, click "**Play**" to run the PC2TVwifi application.



Note: If you are using NVIDIA display card in Windows XP system, it will pop up a notice window, please press "OK" or close, and do not follow the steps to do any settings.

NVIDIA Display
The NVIDIA Display Panel extension cannot be created.
Possible reasons include:
Disabled graphics hardware acceleration. To enable Hardware Acceleration:
1. Right click on your desktop, select Properties, the Settings tab, and click Advanced.
2. Click the Troubleshoot tab and move the 'Hardware acceleration' slider all the way to Full.
3. Click OK.
4. If prompted, restart your computer.
OK

5.1.4 Click "**Stop**" to stop the PC2TVwifi application.

5.2 Advanced “Play” Management of PC2TVwifi Utility

There are more adjustable configurations for you to choose to “**Play**” PC2TVwifi application. Click to open the advanced menu.

1. You can see all of the connected PC2TVwifi devices in the device list. Double click the “device name” to select/change the target device

2. You can also double click to link to the network setting page.(see 5.3)

3. Optimum Mode Settings:
   In order to provide the optimized performance between normal computer applications and video/movies playback, there are three settings for different using scenarios.

   A. The bar of “Optimum Mode” is set at “PC” mode in default for normal PC applications.
   B. If you want to see computer video/movies, set the bar of “Optimum Mode” to “Middle” mode.
   C. If the performance of video/movie is still not acceptable in “Middle” Mode, you can set it to “Movie” mode.

4. The computer audio is disabled in default after “Play” PC2TVwifi application. If you want to listen to the audio/music from both of computer and TV sides, please tick “**Keep PC Audio**”.

   After setting, please click “**Apply**”.

5.3 PC2TV Control

To set the PC2TVwifi device settings

Note: The values of PC2TV Control can be only shown by Internet Explorer 7 or later version



1. **Device Name:**

   To change "**device name**", After change please click "**set**".

2. **Overscan Adjustment:**

   Adjust screen width and height size, After change please click "**save**".

3. **Network Configuration - AP (Access Point) mode:**

   To set the Network setting, After change please click "**save**".

   Note: The setting is not necessary to be changed under normal usage.

4. **Network Configuration - STA (Station / Client) mode:**

   STA Mode (Require Router support DHCP and set DHCP function on)

   Set the SSID and KEY, After change please click "**save**" and restart PC2TVwifi Device, then connect the PC wifi to the router.

   Note: 1.The settings for SSID and KEY have to be the same as the setting in wireless router

   2. The SSID name can not enter space.

5.4 Extend Mode For Windows 7

Right click the mouse on desktop, please select “Screen Resolution”

Select “Connect to a projector” (if there is no “connect to a project”, please press “ +P” on the keyboard.

Please select “**Extend**” as below:

Double click the PC2TV icon on the desktop, click “Play”

Since in Win 7, the default extend resolution is 800 x 600. You can right click the mouse on desktop, select “screen resolution” to change the resolution (max. 1440x 900).

5.5 Upgrade the PC2TVwifi Device

If you are going to upgrade the firmware of PC2TVwifi device, please prepare the suitable firmware package and one USB flash disk.



- Save the entire firmware files under “FirmwareInstall” folder in the root folder of the USB flash disk.

- Plug in the USB flash disk into one of USB ports of PC2TVwifi device, and then power on the device.


PC2TV Firmware Upgrade
PC2TV Version 1.13 → 1.13 (20100326)
Kernel 0.20.00.00.00 → 0.20.00.00
0 %
Installation will begin in 2 seconds

- Wait for a while, the firmware upgrade information will show on the screen.

- The firmware upgrade process will start automatically.

- During the upgrade, please avoid to power off the device, or else you may damage the device.

- After firmware upgraded, please remove your USB flash disk, and the device will reboot automatically.

Q1: If you get bad or poor fluency in playing a video or movie through PC2TV application,

A1: Check the each following status.

(1) **Check Aero Glass themes of Windows 7 / Vista**

1. Right click the desktop and select Personalize.



2. Choose a “Basic and High Contrast Themes” instead of “Aero Themes”.



3. Close the window.

(2) **Check the “Optimum Mode” setting**

1. Click to open the advanced menu.
2. If the “Optimum Mode” is set at an inappropriate mode, please modify it.

A. The bar of “Optimum Mode” is set at “PC” mode in default for normal PC applications.

B. If you want to see computer video/movies, set the bar of “Optimum Mode” to “Middle” mode.

C. If the performance of video/movie is still not acceptable in “Middle” Mode, you can set it to “Movie” mode.

After setting, please click “**Apply**”.

(3) **Check your computer's Desktop Resolution**

If the "Resolution" setting is higher then the maximum supported one of your computer capability, please change the resolution to an appropriate one.



(4) **Change the Wi-Fi Channel**

This solution is only for Wi-Fi connection.

1. Go to the network setting page of PC2TVwifi device.
2. Fix a connected channel instead of "Auto" and "Save" it and then connect the Wi-Fi again.

If the fluency is still poor after fixing a channel, please try other ones.



Q2: If the audio is not worked well after "Play" PC2TV application.

A2: 1. Please check the audio devices on your media player.

2. If the audio is not worked well after "**Stop**" PC2TV application (PC mode), please check the audio devices on your PC.
   2.1 Open the "Sound" from "Control Panel".
   2.2 The "Default Device" in the "Playback" Tab should be set at your PC's hardware audio speakers.
   2.3 If not, select it and then click "OK" or "Apply" to save the setting.
   2.4 Then close your media player and restart-up it again.
3. If the audio is not worked well after "**Play**" PC2TV application (TV mode), please check the audio devices on your PC.
   3.1 Open the "Sound" from "Control Panel".
   3.2 The "**Speakers**" should be set as "**WonderMedia SmartStream Audio**".
   3.3 If not, select it and then click "OK" or "Apply" to save the setting.
   3.4 Then close your media player and restart-up it again.

Q3: If the video is not worked well after "Play" PC2TV application when using NVIDIA display card in Windows XP system.

A3: If you are using NVIDIA display card in Windows XP system, it will pop up a notice window, please press "OK" or close, and do not follow the steps to do any settings.

NVIDIA Display
The NVIDIA Display Panel extension cannot be created.
Possible reasons include:
Disabled graphics hardware acceleration. To enable Hardware Acceleration:
1. Right click on your desktop, select Properties, the Settings tab, and click Advanced.
2. Click the Troubleshoot tab and move the 'Hardware acceleration' slider all the way to Full.
3. Click OK.
4. If prompted, restart your computer.
OK

Q4. When the PC2TVwifi can not search the device.

A4. 1. Check the Device Manager and Local Area Connection Properties, see 3.1.9 Page4

2. Check your computer's Wi-Fi has been linked to the "device SSID" of the PC2TVwifi device, The default of "device SSID" is "**PC2TVwifi**", See 4.2.2 Page7
3. If you have installed other Firewall besides Windows Firewall, please set the **PC2TV** as "allow" or "unblock".

Q5. If the wrong setting ever cause PC2TVwifi not working properly, please refer below for adjustment: (reset SSID & Key under STA mode or back to default AP mode)

1. Power off the PC2TVwifi Device.
2. Connect the PC2TVwifi Device and PC via RJ-45 Cable
3. Power on PC2TVwifi
4. Double click the PC2TV icon on desktop, go to advance menu, click to make network setting.
5. Correct the SSID and Key setting in STA mode or select default AP Mode upon your application.
6. Click Save to save the setting-> remove RJ-45 Cable-> PC2TVwifi device will reboot automatically-> now you can use/connect the device

Q6. The PC2TVwifi can not work when I am in the Ethernet cable application.

A6. Please make sure the Ethernet cable is properly connected on PC2TVwifi first, and then power on the device.

Q7. Supported Display Resolutions

PC2TVwifi Support Resolution Table - 1						
	TV/Monitor	TV / Monitor Highest Support Resolution				Remark
PC		1024x768	1280x800	1280x1024	1366x768	
Resolution Setting of PC's Desktop	800x600	800x600	800x600	800x600	800x600	
	1024x768	1024x768	1024x768	1024x768	1024x768	
	1280x720	800x600	1280x720	1280x720	1280x720	
	1280x768	800x600	1280x768	1280x768	1280x768	If TV does not support 1280x768, then TV will be at 800x600.
	1280x800	800x600	1280x800	1280x800	800x600	If TV does not support 1280x800, then TV will be at 800x600.
	1280x1024	800x600	800x600	1280x1024	800x600	If TV does not support 1280x1024, then TV will be at 800x600.
	1360x768	800x600	800 x 600	800 x 600	1360 x 768	If TV does not support 1360x768, then TV will be at 800x600.
	1366x768	800x600	800 x 600	800 x 600	1366x768	If TV does not support 1366x768, then TV will be at 800x600.
	1440x900	800x600	800 x 600	800 x 600	800x600	If TV does not support 1440x900, then TV will be at 800x600.
	1600x1200	800x600 (PC:1440x900)	800 x 600 (PC:1440x900)	800 x 600 (PC:1440x900)	800x600 (PC:1440x900)	If PC does not support 1440x900, then both of PC and TV will be at 1024x768.
	1680x1050	800x600 (PC:1440x900)	800 x 600 (PC:1440x900)	800 x 600 (PC:1440x900)	800 x 600 (PC:1440x900)	If PC does not support 1440x900, then both of PC and TV will be at 1024x768.
	1920x1080	800x600 (PC:1440x900)	800 x 600 (PC:1440x900)	800 x 600 (PC:1440x900)	800 x 600 (PC:1440x900)	If PC does not support 1440x900, then both of PC and TV will be at 1024x768.

PC2TVwifi Support Resolution Table - 2						
	TV/Monitor	TV / Monitor Highest Support Resolution				Remark
PC		1440X900	1600X1200	1680X1050	1920X1080	
Resolution Setting of PC's Desktop	800x600	800 x 600	800 x 600	800 x 600	800 x 600	
	1024x768	1024 x 768	1024 x 768	1024 x 768	1024 x 768	
	1280x720	1280 x 720	1280 x 720	1280 x 720	1280 x 720	
	1280x768	1280 x 768	1280 x 768	1280 x 768	1280 x 768	If TV does not support 1280x768, then TV will be at 800x600.
	1280x800	1280 x 800	1280 x 800	1280 x 800	1280 x 800	If TV does not support 1280x800, then TV will be at 800x600.
	1280x1024	800 x 600	1280 x 1024	1280 x 1024	1280 x 1024	If TV does not support 1280x1024, then TV will be at 800x600.
	1360x768	1360 x 768	1360 x 768	1360 x 768	1360 x 768	If TV does not support 1360x768, then TV will be at 800x600.
	1366x768	1366 x 768	1366 x 768	1366 x 768	1366 x 768	If TV does not support 1366x768, then TV will be at 800x600.
	1440x900	1440 x 900	1440 x 900	1440 x 900	1440 x 900	If TV does not support 1440x900, then TV will be at 800x600.
	1600x1200	800 x 600 (PC:1440x900)	1440 x 900 (PC:1440x900)	1440 x 900 (PC:1440x900)	1440 x 900 (PC:1440x900)	If TV does not support 1440x900, then TV will be at 800x600. If PC does not support 1440x900, then both of PC and TV will be at 1024x768.
	1680x1050	800 x 600 (PC:1440x900)	1440 x 900 (PC:1440x900)	1440 x 900 (PC:1440x900)	1440 x 900 (PC:1440x900)	If TV does not support 1440x900, then TV will be at 800x600. If PC does not support 1440x900, then both of PC and TV will be at 1024x768.
	1920x1080	1440 x 900 (PC:1440x900)	1440 x 900 (PC:1440x900)	1440 x 900 (PC:1440x900)	1440 x 900 (PC:1440x900)	If TV does not support 1440x900, then TV will be at 800x600. If PC does not support 1440x900, then both of PC and TV will be at 1024x768.